



INSTALLATION INSTRUCTIONS

METHOD 4 – 2 DOORS

WARNING




For the installation of FlyScreen+ V4, only the indicated accessories must be used.

PARTS LIST

- 1 Fly screen
- 2 Adjuster profile (x2)
- 3 Sliding profile (optional)
- 4 Front fixing brackets (left and right)
- 5 Push spring (x2)
- 6 Push group (x2)
- 7 Endcap double door
- 8 Fixing Plate (x2)
- 9 Floor plate
- 10 Cap for endcaps (x2)
- 11 Bracket (x2)
- 12 Double-sided perimeter brush seal

PARTS LIST




TOOLS




Recommended tools and accessories for installation.

LEGEND



Installation and adjustment screws.


1




2

















3
















4











53




If the FlyScreen+ installation has been carried out correctly, it should not be necessary to adjust any misalignment. If it is necessary, proceed as indicated in the following steps.

54




55




56



57



58



59



60

